

TAYAMA®

Compact Dual Fan & Heater



MODEL: TFH-2000A
Power: 1500-Watts 120V~ 60Hz

Read all the instruction carefully before you use the appliance and keep it for future reference.

IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, fire or injury to persons, including the following:

1. Read all instructions before using this heater.
2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9m) from the front of the heater and keep them away from the sides and rear.
3. Do not operate heater unattended. Use of extreme caution is necessary when any heater is used by or near children, disabled persons or pets.
4. Always unplug heater when not in use.
5. Do not operate heater with a damaged power cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater or return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
6. Do not place the heater on a small, unlevel, uneven or any surface which might allow heater to tip or fall.
7. For proper operation, heater should be placed on a smooth, non-combustible surface. Do not place on rugs or carpet.
8. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into bathtub or other water container.
9. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
10. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
11. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
12. A heater has hot and arcing or sparking parts inside. Do not use near combustible materials or flammable gases or sources of heat. DO NOT USE in areas where gasoline, paint, or flammable liquids are used or stored.
13. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or

injury to persons.

14. CAUTION: Always plug heaters directly into a wall outlet/receptacle. Avoid the use of an extension cord because the extension cord may overheat and cause a risk of fire.

15. To prevent overloading a circuit, do not plug the heater into a circuit that already has other appliances working.

16. The output of this heater may vary and its temperature may become intense enough to burn exposed skin. Use of this heater is not recommended for persons with reduced sensitivity to heat or an inability to react to avoid burns.

17. Do not use heater outdoors.

SAVE THESE INSTRUCTIONS HOUSEHOLD USE ONLY

WARNING: In order to avoid overheating, do not cover the heater.

The heater must not be located immediately below or in front of a socket outlet. The device must not be placed near curtains or other flammable materials. Do not touch body of heater when in use. This heater is hot when in use, to avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater.


The supply cord has a polarized plug. As a safety feature this plug will fit in a polarized outlet only one way. To prevent electric shock, match wide blade of plug to wide slot, fully insert plug. If the plug does not fit contact a qualified technician. Never use an extension cord unless plug can be fully inserted. DO NOT attempt to alter this safety feature.

Features

- Optimal space saving design, the fan can be positioned horizontally or vertically
- Adjustable thermostat control
- 3 Settings: High 1500 Watts / Low 750 Watts / Fan Only
- Power indicator light
- Safety overheat protection
- Metal safety grill

Operation Instructions


1. **HEATER OPERATION:** Always operate the heater in the vertical position or horizontal position or horizontal position following all instructions and recommendations listed in this manual.
2. **HEATER LOCATION:** Place the heater in the area of the room that is the coldest.
3. **HEATER CONNECTION:** Plug the heater directly into 120V AC 60 Hz wall outlet. Be sure plug fits tightly in the outlet. A loose connection may cause overheating and damage to the plug or heater. NOTE: To prevent overloading a circuit, do not plug into a circuit that is servicing other electrical needs.
4. **HEATER POSITION:** For space-saving convenience, this heater can be used in a horizontal or vertical position as shown below.
5. **POWER INDICATOR LIGHT:** The heater is equipped with a Power Indicator Light. The power light will illuminate when the unit is turned on.
6. **TURNING ON HEATER:** To start the heater, turn the Power Control dial from OFF "O" position to the LOW "I" or HIGH "II" setting. Then rotate the Thermostat position as described below. (During the heaters initial use, you may experience a slight odor or smoking. This is the result of the heating element lubrication "burning off". This is normal and will go away after a few minutes of use.)
7. **POWER CONTROL DIAL:** This heater has two heat settings: High and Low. Use the higher setting (1500W) to raise the room temperature quickly. When the desired temperature is reached use the Low settings (750W). It is usually sufficient to maintain a comfortable temperature.
8. **SETTING THERMOSTAT:** After heater has been turned on and the room has reached the desired temperature, slowly rotate the thermostat knob counter-clockwise until the heater shuts off. By leaving the thermostat at this setting it will automatically maintain this temperature. To lower temperature, rotate the thermostat knob clockwise (towards the HIGH position).

9. **TO OPERATE FAN** : Turn the Power Control dial to the Fan setting. Turn thermostat fully clockwise so the fan will run continuously.
10. **TURNING OFF:** Turn the Power Control dial to the OFF position before unplugging or plugging in the heater. Heater should be unplugged when not in use.
11. **SAFETY FEATURE:** The power indicator light (located near the control panel) will illuminate whenever the heater of fan is plugged in. The heater is equipped with an automatic over heat shut-off protection device located inside the body of the heater. If the heater grill is obstructed, or if the heater gets too hot, the heater will automatically shut-off. To reset the heater, turn power off and unplug the heater for 10 minutes until it cools down and you may plug in and restart the heater. Make sure the heater is on a smooth level surface with no obstructions.

Care & Maintenance

1. **CLEANING:** Before cleaning, please make sure to turn off the power and disconnect the power cord and allow the heater to cool completely. Clean the outside surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSER THE HEATER IN WATER. Allow heater to dry completely before use.
2. **STORAGE:** Keep original carton for storing away the when no longer in use.

Parts Diagram



Tayama Appliance USA Inc.
www.tayama-usa.com
support@tayama-usa.com