TAYAM

PARTS DIAGRAM

Steps for usage


Please follow the steps shown

in the figure below to operate


Basic safety precautions should always be followed:

Important Safeguards

- Please remove grill from all packaging and read all instructions prior to use.
- Make sure grill is set up correctly before use.
- Be sure to completely extinguish after use.
- For use with charcoal only.
- Before using, add water to the bottom of the furnace basin and furnace body to help reduce the fumes and smoke during usage.
- Use the charcoal grill on a high temperature heat resistant tabletop surface to prevent damage to the tabletop.
- Never leave the charcoal grill unattended while grilling.
- Do not attempt to move the charcoal grill while grilling to avoid personal injury.
- Do not use charcoal grill where fire is prohibited.
- Before cleaning or moving, make sure the charcoal grill has been completely extinguished and is safe to handle.
- For outdoor use only.

















1.Add water in the bottom





4.Charcoal ignition

2.Put in charcoal basin

6.Grill pan for grilling food

Tayama Appliance USA Inc.

www.tayama-usa.com



Model TYG-808

Please read all instructions carefully before operating the grill and keep for future reference.